



Nuova Rade

Marine - Plastics Technology Experts

Instructions for Installation & Use of Hatches

The following instructions concern the below Nuova Rade Hatches:

- KROME
- TOP LINE
- MID LINE
- CLASSIC
- INDUSTRIAL
- Inspection Hatches
- Storage Hatches



- Install using only natural silicone without benzene, acetone, etc.
- Don't expose to aromatic (benzene, etc.) or acid concentrates.
- Don't use acetone, toluene, or cleaners containing solvents.
- Original luster and appearance may be protected by cleaning with hot soapy water.

** During installation, a maximum torque of 6 N·m should be used to screw the hatch down.
In order to avoid damage to the hatch, the screwdriver and screw sizes should match the hole size.*